





Installation Instructions

1. **Disconnect Battery.** **Do not skip this step.** Also, do not try to “test” the LED array by connecting the leads directly to your battery. Permanent damage will occur to the LED array if you fail to heed these steps.
2. Remove Taillight Lens.
3. Remove light bulb.
4. Remove and save the boot on the back of the taillight.
5. Disconnect the harness from the taillight by turning the plastic connector clockwise.
6. Choose a location to splice to the old harness. This can be in the quarter panel or in the trunk. The trunk is preferred, but the supplied connectors are waterproof so connection in the quarter panel will not cause any problems. Cut the old harness at your chosen location. The taillight harness consists of black and pink wires on the driver’s side or black and purple wires on the passenger side.
7. Pass the supplied LED harness through the taillight to the desired location. The plastic connector should be about three inches beyond the taillight. Reinstall the boot on the back of the taillight.
8. **Driver’s side.** Using the supplied connectors, connect the black wire on your car to the black wire on the supplied harness. To use the connector: put both wires in a separate hole, unstripped. Holding the wires as far in as possible, squeeze the connector with pliers. Some “goo” may come out of the connector. This “goo” ensures a watertight connection. Repeat by connecting the pink wire on your car

to the red wire on the supplied harness.

9. **Passenger side.** Using the supplied connectors, connect the black wire on your car to the black wire on the supplied harness. To use the connector:

QUICK & EASY!

- ① Strip wire 1/2" 
- ② Twist 
- ③ Insert 
- ④ Hand tighten 

10. Repeat by connecting the purple wire on your car to the red wire on the supplied harness.
11. Attach the plastic connector on the supplied harness to the LED array.
12. Remove one of the screws that attach the mounting bracket at the bottom of the LED array. Attach the green wire on the supplied harness to this screw and reattach the screw to the LED array.
13. Without the lens gasket installed, place the LED array in the taillight housing.
14. Position the LED array as needed and tighten the three screws
15. Position the lens gasket and reinstall the lens. Do not over tighten the lens screws!
16. Repeat for the other side.
17. Reconnect the battery.
18. Test both STOP and taillight functions.
19. Enjoy!

Technostalgia

1889 E Telegraph Hill Rd

Madison Indiana 47250

812-265-0062

e-mail: info@cool-leds.com